

DAY BED ASSEMBLY INSTRUCTIONS



STEP 1:

Bolt the ladder back to the 2 sides.

Use the 5" bolts with the ½" hex head. Make sure to use the washers included. Do not attach the mattress trampoline yet.



STEP 2:

Put the trundle in the pop-up position.



STEP 3:

Line up the trundle to the assembled day bed frame and mark where the pop-up sits so that you can attach the trampoline to line up with the trundle when it is in the up position.



STEP 4:

Attach the trampoline at the marked height.

Cover the bolt holes with the wooden plugs.

Enjoy your unique aspen day bed!