

SLAT INSTALLATION INSTRUCTIONS



STEP 1:

Assemble the bed with the flat rails on the bottom facing towards the inside of the bed.

IMPORTANT NOTE: The inverted "T" mark should run along the top.



STEP 2:

Attach each slat on the left and right to match up with the "T" mark as shown.



STEP 3:

Line up each slat and screw the left and right sides together.



STEP 4:

Once the slats are all attached together and the bed is in the desired location, attach a center support to each run of slats. (Center supports are not necessary for twin size beds.)